


MOTO SPARK
M3
USER MANUAL



MOTO SPARK USER MANUAL M3

CONTENTS

1 PRODUCT INTRODUCTION	A2
1.1 PRODUCT OVERVIEW	A2
1.2 PRODUCT ACCESSORIES	A3
1.3 SPARK FABRICA GRANULE	A3
2 TECHNICAL PARAMETER	A4
3 SCREEN OPERATION GUIDE	A5
3.1 BACK PANEL INTRODUCTION	A5
3.2 MENU SETTING	A6
3.3 STATUS ICONS	A7
3.4 DMX PARAMETER LIST	A7
4 OPERATION NOTES	A8
4.1 WORKING CONDITION REQUIRED	A8
4.2 SAFETY TIPS	A9
5 Battery	A9
5.1 Type of battery	A9
5.2 Installation of battery	A9
5.3 How to charge battery	A9
5.4 Maintenance of battery	A9
5.5 Auto-switch between battery and AC	A10
6 MACHINE OPERATION	A10
6.1 PREPARATION	A10
6.1.1 INSTALL MACHINE	A10
6.1.2 FILL IN SPARK FABRICA GRANULE	A11
6.2 CONNECT MACHINE	A11
6.3 INITIAL SETTING	A12
6.3.1 SET CHANNEL MODE	A13
6.3.2 SET DMX ADDRESS	A13
6.4 SWIPE RFID TIME CARD	A13
6.5 START TO SPARK	A13
6.5.1 TURN ON CONSOLE'S POWER	A13
6.5.2 TURN ON HEATING FUNCTION	A13
6.5.3 ADJUST SPARKING HEIGHT	A14
6.5.4 HOW TO SET THE REMOTE CHANNEL OF REMOTE CONTROLLER	A15
6.5.5 HOW TO USE REMOTE CONTROLLER TO CONTROL THE MOTO SPARK	A15
6.6 CLEAR MATERIAL	A16
6.7 CLEAN MACHINE	A16
7 MACHINE MAINTENANCE	A16
8 FAILURE HANDLING	A17

CHANGSHA SPARK TECHNOLOGY ELECTRONICS CO.,LTD

www.sparkfabrica.com

SPARK FABRICA

DISCLAIMER

Please read the manual carefully before installing and using this product. Failure to read or comply with this manual may result in injury to products and personnel, and Spark Fabrica shall not be responsible for this.

This product is a professional machine, we do not assume any responsibility for accidents or losses caused by the use or maintenance of this product by personnel without professional training and permission.

If the information contained in the manual or the product specifications are changed, Spark Fabrica will not inform you further and responsible for any errors or omissions.

Our company reserves the right to modify the user manual at any time

PREFACE

*This manual includes warning, caution and notice concerning the safe operation of equipment. These warning-caution and notice come with the following icons. Please read them carefully!

WARNING

This warning indicates a dangerous situation that may result in death or serious injury if not avoided.

CAUTION

This alert indicates a dangerous situation that may result in mild or moderate injury if not avoided.

NOTICE

This means that you need to be careful.


1. PRODUCT INTRODUCTION

This product belongs to special effects equipment, only for professional use.

This product belongs to the cold fireworks simulation special effects equipment, using CST technology, heating special metal powder, and sparking silver spark fountain which is safer than the traditional cold fireworks. It has three controllable variables: height, density and duration.

This product is widely used in weddings, concerts, sports events, event meetings and so on. Stimulate your interest and light up your activity.

1.1 PRODUCT OVERVIEW



1.2 PRODUCT ACCESSORIES

1 Adapter

User Manual

NOTICE

Open the package carefully and check to make sure the goods are in good condition.

1.3 SPARK FABRICA GRANULE

A special metal powder has the characteristics of high content, little residue, belonging to a special consumables with no smoke, odor and other harmful gas when sparking.

WARNING


Only the consumables provided by Spark Fabrica are allowed to be used. Spark Fabrica shall not be liable for any damage to machines, personnel and property caused by the use of consumables not provided by the company.

2 TECHNICAL PARAMETER


Identification	Manufacturer	SPARK FABRICA
	Name	MOTO SPARK
	Model	M3
	Input Voltage & Frequency	100-120V, 60Hz 200-240V, 50Hz
	Current Limiter Specifications	6.3A,100-120V / 6.3A,200-240V
	Constant Current	5.5A,100-120V / 2.7A,200-240V
AC Power	Nominal Total Power Consumption	450W
Heating	Heat Up Time	<10minutes under battery mode
Hopper	Powder Tank Capacity	150g
	Removable Hopper	N/A
	Linearly Adjustable Density	100%
	Adjustable Height	2-5m
	Height Level	1-10 Level
	Powder Consumption (100% Output)	17-20g/Minute
Technical Parameters	Maximum Single Continuous Duration	30s
	Control Protocol	DMX-512
Control	RFID Proximity Card	✓
Accessory	Power	Adapter
	Safety Ring	Optional
Certification	CE	✓
	ROHS	✓
	FC	✓
Weight	Net Weight	12kg
	Gross Weight	14kg
Dimensions	Machine Dimensions - L*W*H	220X240X285mm
	Packing Dimensions - L*W*H	290X290X380mm
Granule	Granule	Spark Fabrica granule

3 SCREEN OPERATION GUIDE

3.1 BACK PANEL INTRODUCTION



3.2 MENU SETTING



NOTICE

Press <OK> to enter the menu setting. The screen will automatically return to the main state interface with no modification.


NOTICE

Press ▲ key or ▼ key to modify parameters. The parameters will be flash after the modification, and please press <OK> key to save the change.

NOTICE

Press ▲ key will return to previous page.

3.3 STATUS ICONS



NOTICE

When the icons are green means the machine is working normally, and yellow means abnormal.

	Wireless Connection		Blower Motor
	Shaft Motor		Hopper Motor
	Temp Sensor Unconnected		Temp Over Heat
	Tip Over		Lack Of Time
	PCB Too Hot		Sub PCB Connected
	2 Channel Mode		Battery mode
	AC mode		

3.4 DMX PARAMETER LIST

First Channel	Function
0~10	Stop
11~255	Fountain Height
Second Channel	Function
0~200	Pre-heat Off
11~39	Emergency Stop
56~200	Clear Material
240~255	Pre-heat On

NOTICE

The DMX address of safety channel must above 200

4 OPERATION NOTES

Please read the following Operation Notes carefully before working with the machine.

4.1 WORKING CONDITION REQUIRED



Do not mount the product on a flammable surface (linoleum, carpet, wood, paper, carton, plastic, etc). Make sure there are no inflammable or combustible materials in the using environment.



Do not use in a confined space. Always install the product in a location with adequate



This product has no lightning arrester, please do not use this product in thunderstorm



Keep people or flammable materials at least 10 feet (3 meters) away from the machine, and make sure that debris does not fall on flammable objects.



Do not use the machine at temperature above 122 °F (50 °C).

4.2 SAFETY TIPS



Always connect the ground wire to avoid electric shock. The machine cannot be submerged in water while operating it.



Do Not touch the sparks. During heating up and operation, do not touch the housing.



The product is very hot during operation and it remains hot for a long time after operation has stopped. Do not touch or put finger in the output nozzle.



The noise level generated from the spark machine unit is estimated of 80dB depending on the point nearest to the machine(s) during operational discharge mode.



Wear eye protection to avoid eye injury while filling granules and testing spark machine(s).



The proper firefighting extinguishers are recommended as follows: Any type of sand or substance that can suffocate the active metals. Class "D" Fire Extinguishers for Metal Substance Fires.

5 BATTERY

5.1 TYPE OF BATTERY

This machine can take 21 pieces of 21700 Li-on cell battery. Which can support 2 hours firing time.

5.2 INSTALLATION OF BATTERY

This machine must install 21 pieces of battery. Less battery will lead to malfunction of machine or result in battery explosion due to overloaded charging current.

Please follow the instruction on the battery panel to install the battery.

Do not install battery upside down.

5.3 HOW TO CHARGE BATTERY

Connect the power plug to AC, turn on the machine, go to screen to choose BATTERY CHARGING MODE from the menu. Then it will start charging the battery.

Connect the power plug to AC, turn on the machine, go to screen to choose BATTERY CHARGING MODE from the menu. Then it will start charging the battery.

5.4 MAINTENANCE OF BATTERY

5.5 AUTO-SWITCH BETWEEN BATTERY AND AC


When you plug off the power cable, machine will automatically switch to battery mode.

When you plug in the power cable, machine will automatically switch to AC mode.

6 MACHINE OPERATION


6.1 PERPARATION

Install the machine on a firm and level ground, and the maximum tilt angle shall not exceed 15 degrees.



6.1.1 INSTALL MACHINE

Install the product on truss by using the attached accessories.



WARNING

Keep people or flammable materials at least 10 feet (3 meters) away from the machine, and make sure that debris does not fall on flammable objects.

*Specific installation notes please refer to "4 OPERATION NOTES".

6.1.2 FILL IN SPARK FABRICA GRANULE

Spark Fabrica Granule is the consumable specially designed for spark machine, to simulate cold fountain fireworks effect for stage.

*Tear the vacuum package of granule, and fill in the Spark Fabrica Granule through the granule filling port on the top of the machine.

*Fill the consumable into the feed port. NOT into the output nozzle.

*Close the lid securely after filling.

*The capacity of storage bin is 150g.



WARNING

Make sure to fill the Spark Fabrica Granule through the feed port on the top of the fixture when power supply is off.

WARNING

Wear eye protection to avoid eye injury while filling granules and testing spark machine(s).

WARNING

Do not use damaged power plug and power cable. One power plug is recommended to connect 4 units in series at most for this product.

6.3 INITIAL SETTING

Setting	Range	Default
Set Temperature	680-700	680
DMX Address	1-512	1
DMX Channel Mode	2/8	2
Density	30~100	100
Safety Address	0-512	OFF(0)
Tilt Sensor	ON/OFF	ON
Restore Defaults	YES/NO	NO
TFT BackLight	ON/OFF	ON
Auto Heating	ON/OFF	OFF

*Turn on power

*Check the machine status icon(refer to icon introductions of 3.3)

 CAUTION

When the icon shows yellow, it indicates that the machine is abnormal. Please use it after asking the professional to check and repair the machine.

*The sparking temperature of the machine is the factory default temperature. The product will heat up automatically when disconnected with DMX signal. Automatic heating function can be set to on or off, and the concrete operation please refer to "3.2 MENU SETTING".

When spark machines connect DMX signal, the heating function can be started only on the Sim Pyro Console

6.3.1 SET CHANNEL MODE

 CAUTION

This machine has 2 channel mode and multiple channel mode, the specific setting please refer to "3.2 MENU SETTING".

6.3.2 SET DMX ADDRESS

Please set DMX address according to channel mode:

*In the 2 channel mode, please set spark machines' DMX address to 1.3.5.7.....

 NOTICE

Please do not set address code repeatedly.

6.4 SWIPE RFID TIME CARD

In order to avoid machine failure or other safety accidents caused by bad-qualified consumables, this product can only be used with special RFID time card.

 NOTICE

Each swipe of the card can be recharged for 12 minutes, and each machine can swipe up to 2 time cards for 24 minutes at most. The card can only be swiped again when the remaining time is less than 20 minutes.

 NOTICE

If the customer breaks the card swiping function or cancels the card swiping function at the customer's request, no quality guarantee and aftersales service will be provided by Spark Fabrica. Spark Fabrica shall not be liable for any accidents and losses about this.

6.5 START TO SPARK

The machine can be controlled by Pyro Sim Controller console or DMX512 console.

6.5.1 TURN ON CONSOLE'S POWER

6.5.2 TURN ON HEATING FUNCTION

NOTICE

The heating function of the second channel DMX value is 240~255, and it takes about 5 minutes to preheat after turning on.

NOTICE

When heating is turned on, the <HEAT> indicator light on the machine will turn to red, and the <READY> indicator light flashes green to indicate that the machine is heating.

NOTICE

Heating will complete after the <READY> indicator light turns green for a long time, and the spark machine will enter sparking status.

NOTICE


When using the Pyro Sim Controller controller, the screen will display the real-time temperature of each machine. When the temperature value of the control board turns green, it means that the heating is completed and the machine enters the status of sparking.

6.5.3 ADJUST SPARKING HEIGHT

Adjust sparking height through the first channel, and the height adjustment values is DMX parameter values 11-255

NOTICE

The proper firefighting extinguishers are recommended as follows: Any type of sand or substance that can smother the active metals. Class "D" Fire Extinguishers for Metal Substance Fires.



6.5.4 HOW TO SET THE REMOTE CHANNEL OF REMOTE CONTROLLER

The remote controller provides 12 remote channel options. Turn on the power of remote controller, Hold button 12 for 5 seconds until the led light flash, then please choose the 1-12 button on the remote controller, hold the selected button for 8 seconds.

6.5.5 How to use remote controller to control the moto spark

If the remote controller set the remote channel between 1-12, lets make 2 for example. Then we choose the RF channel on the machine screen to 2, then the remote controller can control the machine.

1	ON	2	ON	3	15S
4	OFF	5	OFF	6	30S
7	LOW	8	HIGH	9	CLEAR
10	HEAT ON	11	HEAT OFF	12	OFF/CODE

CAUTION

The remote controller can be used after coding when DMX signal is disconnected, or the function will be broken.

⚠ CAUTION

Sparking stops automatically after 30 seconds, and clearing material stops after 5 seconds.

⚠ CAUTION

The remote controller has 4 height levels.

6.6 CLEAR MATERIAL

This product has the function of cleaning material, which can clean up the heated but not sparked consumables, so as to avoid nodulation in the heating chamber and causing stuck machine.

NOTICE

Use the cleaning function of the second channel for cleaning, DMX value is 56-200.

NOTICE

This function must be performed at the end of each show.

6.7 CLEAN MACHINE

After clearing material, please clean the machine to extend the service life of the machine.

*Turn off the machine's power.

*Remove power connection and DMX signal cable.

*Use a damp cloth to remove dust and debris from the surface of the machine.

*Unused Spark Fabrica Granule should be stored in a cool, dry place, vacuum packed in sealed foil bags, and protected from moisture, heat, hot surface, open fire and other ignition sources.

7 MACHINE MAINTENANCE

Some steps are needed in order to clean and maintain the product for maximum usage. The recommended procedure is as follows:

⚠ CAUTION

After a period of using, check if there is any consumable accretion inside the nozzle. Do necessary cleaning up if there has some, or it may affect spark performance, even damage the machine.

8 FAILURE HANDLING

Error Code	Description	Solution
Bat Voltage LOW E0	Battery voltage UN-normal	Replace main board 1.Restart machine to clear alerts, stop operating for 15 minutes until temperature return to normal. 2.Check wire connection of motor 3.Replace motor 4.Replace main board
Motor Protect E1 M1	Blower motor protection/ disconnected	1.Shift motor clog (perform clean material function manually) 2.Check wire connection of motor 3.Replace motor 4.Replace main board
Motor Protect E1 M2	Shaft motor protection/ disconnected	1.Hopper motor clog (perform clean material function manually) 2.Check wire connection of motor 3.Replace motor 4.Replace main board
Motor Protect E1 M3	Hopper motor protection/ disconnectd	1.Check wire connection of temperature sensor 2.Replace Temperation sensor 3.Repalce Main board
Temp Sensor E2 Unconnected	Temperature sensor disconnected	Stop operating machine until main board temperature return to normal
PCB Too Hot E3	Main board too hot	Please scan new RFID card
Time Remain E4	Insufficient time	Stop operating machine until temperature return to normal. Alert will clear off automatically.
Temp Over Heat E5	Heating protection due to over-temperature.	1.Inspect Wire connection of heating board. 2.Replace heating coil 3.Replace heating board
Heat Fail E6	Heating process fail	Machine will activate tip over protection if the angle is more than 45 degrees. The alert will clear off automatically after put the machine back to normal positon.
Tip Over E7	Tip over alert	1.Check wire connection of Sub-PCB 2.Replace Sub-PCB 3.Replace Main Board
Sub PCB Unconnected E8	Sub-PCB disconnected	Use illegal or copy RFID card will lock the machine. If so, seller will stop providing warranty and after sale service. To unlock the machine, please contact seller.
Illegal Card Machine Locked	Machine locked because of using illegal or copy RFID card.	

Spark Fabrica

www.sparkfabrica.com



marketing@sparkfabrica.com

+86 138 7585 1139