

Instructions for use of LED stage lighting equipment

LED MINI MOVING HEAD LIGHT BEAM



Please read the instructions carefully before using

● **Light Menu description**

Addr	A001-A512	512 Address setting
CHnd	14CH	14 Channel setting
	12CH	12 Channel setting
SLnd	Auto	Mainframe self-walking mode
	SL 1	Control station mode
	SL 2	Auxiliary mode
SHnd	SH 0	Effect 0 (recommended)
	SH 1	Effect 1
	SH 2	Effect 2
	SH 3	Effect 3
Soud	ON	Voice controlled open
	OFF	Voice control switch
SEnS	0-99	Voice-controlled sensitivity volume regulation
LEd	OFF	Five seconds later, screen out.
	ON	The screen is always on
dISP	no	Display reverse
	YES	Display forward
rPAN	no	X motor forward rotation
	YES	X motor reversal
rTiL	no	Y-motor positive rotation
	YES	Y-motor inversion
REST	YES	system reset

Channel Model Description

14channel mode

Channel	function	explain
1	Horizontal operation	0-255
2	Horizontal fine-tuning	0-255
3	Vertical operation	0-255
4	Vertical fine-tuning	0-255
5	Horizontal and vertical speed	0-255
6	Dimming	0-255
7	strobeflash	0-255
8	Red tone light	0-255
9	Green tone light	0-255
10	Blue tone light	0-255
11	White tone light	0-255
12	Color walking	0-255
13	No effect	0-59
	Self walking	60-159
14	Lamp belt control	250-255 (5 second)

12channel mode

Channel	function	explain
1	Horizontal operation	0-255
2	Vertical operation	0-255
3	Horizontal and vertical speed	0-255
4	Dimming	0-255
5	strobeflash	0-255

