

## Product warranty card (Customer sheet)

Product name: \_\_\_\_\_ Product model: \_\_\_\_\_

Factory No: \_\_\_\_\_

date of production: \_\_\_ year \_\_\_ month \_\_\_ day

Customer Name: \_\_\_\_\_ contact number: \_\_\_\_\_

Customer address: \_\_\_\_\_

1. Warranty content: \_\_\_\_\_

Customer signature: \_\_\_\_\_

2. Warranty content: \_\_\_\_\_

Customer signature: \_\_\_\_\_

3. Warranty content: \_\_\_\_\_

Customer signature: \_\_\_\_\_

## SPARK EFFECT SP-1500W FOG



### display screen

1 Menu 2 Add 3 Subtract 4 Confirm

P001-P100: Oil pump working (smoke spraying)

R000-255: Red

G000-255: Green

B000-255: Blue

DMX512

① Channel: Oil pump working

② Channel: Red

③ Channel: Blue

④ Channel: Green

⑤ Channel: Strobe speed

⑥ Channel: self-propelled

Remote control

FDG: Oil pump working (smoke spraying)

R: Red light+oil pump working (smoke spraying)

G: Green light+oil pump working (smoke spraying)

B: Blue light+oil pump working (smoke spraying)

Note: Remote control not available after connecting

DMX512

### Notes:

When the equipment is oil-free, the air pump will directly spray out the remaining oil mixed with air

So: after refueling the equipment, it needs to be sprayed first to ensure that there is no air in the internal pipelines before it can work properly

When there is no oil, do not forcefully empty the pump. Excessive empty pumping can cause damage to internal parts. If the equipment is damaged due to empty pumping, our company does not provide free repair parts

Disclaimer: If non factory standard e-liquid is used and the equipment malfunctions, there is no warranty

### Product maintenance:

The smoke machine only requires minimal maintenance, please follow the following steps for long-lasting performance

1. After use, let the equipment's oil extraction pipe pump clean water to clean the oil pump
2. After use, wipe the body clean
3. Keep the inside and outside of the machine dry when not in use
4. When adding e-liquid, do not mix in debris and debris, otherwise it may cause product damage