

specialfx.it
18*12W RGBWAU
6IN1 LED PAR LIGHT
IP65
Instruction manual



Please read the instructions carefully before using

1. technical parameters :

voltage : AC100-220v 50-60Hz

power : 216w

LAMP: 18*12w RGBWAU .6IN1

function : Electronic dimming from 0-100% (no color change); High speed white light or variable color flashing, frequency 1-13hz; The light source life is 6-100 thousand hours

CH: 8CHS

Mode: master-slave, self-walk, voice control, DMX512

Lens Angle: 25 degrees

IP:IP65

Size: 256*256*314mm

N.G: 5.5kg

K.G: 6.5kg

☞ DMX MODE

6 Channels Mode

Channel	Function	Instruction
CH1	R Dimmer	Red Dimmer- Dark to Bright
CH2	G Dimmer	Green Dimmer- Dark to Bright
CH3	B Dimmer	Blue Dimmer- Dark to Bright
CH4	W Dimmer	White Dimmer- Dark to Bright
CH5	A Dimmer	Amber- Dark to Bright
CH6	U Dimmer	Ultraviolet- Dark to Bright

10 Channels Mode

Channel	Function	Instruction
CH1	Total Dimmer	RGBW Total Dimmer- Dark to Bright
CH2	R Dimmer	Red Dimmer- Dark to Bright
CH3	G Dimmer	Green Dimmer- Dark to Bright
CH4	B Dimmer	Blue Dimmer- Dark to Bright
CH5	W Dimmer	White Dimmer- Dark to Bright
CH6	A Dimmer	Amber- Dark to Bright
CH7	U Dimmer	Ultraviolet- Dark to Bright
CH8	Total Strobe	RGBW Total Flash Strobe- Slow to Fast
CH9	Function Choice	000~050: CH1-CH8 Control. 051~100: Different Colors output 101~150: Colors Jump Change. 151~200: Colors Gradate.

		201~250: Colors Pulse Change. 251~255: Sound-Active
CH10	Function/Speed	Slow to Fast (At the Colors output and sound choose the color)

☞ KEYS INSTRUCTION



☞ DIGITAL SHOW FUNCTION FORM

No	Show	Function	Value	Instruction
1	d001	DMX address	001~512	6CH mode,UP,DOWN increase or reduce the value,
2	A001	DMX address	001~512	10CH mode UP,DOWN increase or reduce the value
3	r255	Red dim	000~255	UP,DOWN Change brightness
4	G255	Green dim	000~255	UP,DOWN Change brightness
5	b255	Blue dim	000~255	UP,DOWN Change brightness
6	u255	White dim	000~255	UP,DOWN Change brightness
7	y255	Amber dim	000~255	UP,DOWN Change brightness
8	P255	Ultraviolet dim	000~255	UP,DOWN Change brightness
9	FH99	Strobe	01 ~ 99	UP,DOWN change the speed
10	CL01	Colors choose	01 ~ 08	UP,DOWN Change color
11	CC99	Colors Jump	01 ~ 99	UP,DOWN change the speed
12	DE99	Colors Gradate	01 ~ 99	UP,DOWN change the speed
13	CP99	Colors Pulse	01 ~ 99	UP,DOWN change the speed
14	SU01	Colors sound-Active	01~09	UP、DOWN Change the effects

