


# Washer Wall Light



## USER MANUAL



At first, thank you for purchasing the device. For the sake of safety and regular operation of this projector, please read this manual carefully before using and operating it in order to avoid any personal injury or damage to the device.

## WARNING

FOR YOUR OWN SAFETY, PLEASE READ THIS USER MANUAL  
CAREFULLY BEFORE YOUR INITIAL START-UP!



CAUTION: Keep this equipment away from rain,  
moisture and liquids.



### SAFETY INSTRUCTIONS

Every person involved with the installation,  
operation & maintenance of this equipment should:

- Be competent
- Follow the instructions of this manual



CAUTION: Take care using this equipment!  
high voltage-risk of electric shock!!




Before your initial start-up, please make sure that there is no damage caused during transportation. Should there be any, consult your dealer and do not use the equipment.

To maintain the equipment in good working condition and to ensure safe operation, it is necessary for the user to follow the safety instructions and warning notes written in this manual.

Please note that damages caused by user modifications to this equipment are not subject to warranty.

### Digital display operate:

a). Illustration part:



MENU      UP      DOWN      ENTER  
A            B        C        D

A.MENU

B.UP

C.DOWN

D.ENTER

### Operation Instructions:

After startign press A(MENU) Enter into main-menu,  
Press B(UP) C(DOWN) to select the submenu,  
and then press D(ENTER)ensure.

SETTING MENU LED DISPLAY:

Mode	Programming		Description		
Auto mode	Auto		Mode Auto-run mode		
DMX Mode	Addr	3CH	A001-A510	Each channel mode is a separate address, plugged into the console, automatically enter DMX mode	
		5CH	A001-A508		
		8CH	A001-A505		
		24CH	A001-A489		
		48CH	A001-A465		
		53CH	A001-A460		
Show	Shou	Sh1-54	Program Show 1-54		
		Sp1-10	Program Speed 1-10 (slow-fast)		
		St0-9	Program Flash 0-9 (slow-fast)		
Sound Mode	Soud	Sou1	Sen1-9	Mic Sensitivity	
		Sou2			
		Sou3			
Edit color	Colo	R000-255	Red(0-100%) Red Dimming		
		G000-255	Green(0-100%) Green Dimming		
		B000-255	Bule(0-100%) Bule Dimming		
		St0-St9	LED Strobe (slow-fast)		
Static colors	Stat	CL00-CL26	RGB static color		
Slave	Slav	Slave	Slav(Slave,automatically identify the host)		
Information	Info	Ver	VVxx	Soft version	
Product Set	Set	dis	10s	Set the backlight of the display board, from 10 seconds to continuous light, factory default is 10 seconds.	
			20s		
			30s		
			60s		
			on		
		dir	➡	Setting direction right	
			⬅	Setting direction left	

## DMX Channel Tables:

### DMX MODE1:3 CH

CH1	0-255	ALL RED (0-100%)
CH2	0-255	ALL GREEN (0-100%)
CH3	0-255	ALL BLUE (0-100%)

### DMX MODE2:5 CH

CH1	0-255	Dimmer (Master dimmer)	
CH2	0-9	No Function	
CH2	10-255	Slow->Fast	Strobe (Strobe)
CH3	0-255	ALL RED (0-100%)	
CH4	0-255	ALL GREEN (0-100%)	
CH5	0-255	ALL BLUE (0-100%)	

### DMX MODE3:8 CH

CH1	0-255	Dimmer (Master dimmer )
CH2	0-255	ALL RED (0-100%)
CH3	0-255	ALL GREEN (0-100%)
CH4	0-255	ALL BLUE (0-100%)
CH5 (When CH6 value <10, this DMX Channels is valid)	0-9	No Function (CH2-Ch4 effective)
	10-13	Static color(CH7 Choice)
	14-17	Built-in effects 1
	18-21	Built-in effects 2
	22-25	Built-in effects 3
	26-29	Built-in effects 4
	30-33	Built-in effects 5
	34-37	Built-in effects 6
	38-41	Built-in effects 7
	42-45	Built-in effects 8
	46-49	Built-in effects 9
	50-53	Built-in effects 10
	54-57	Built-in effects 11
	58-61	Built-in effects 12
	62-65	Built-in effects 13
	66-69	Built-in effects 14
	70-73	Built-in effects 15
	74-77	Built-in effects 16
	78-81	Built-in effects 17
	82-85	Built-in effects 18
	86-89	Built-in effects 19
	90-93	Built-in effects 20
	94-97	Built-in effects 21
	98-101	Built-in effects 22
	102-105	Built-in effects 23
	106-109	Built-in effects 24
	110-113	Built-in effects 25
	114-117	Built-in effects 26

CH5 (When CH6 value <10, this DMX Channels is valid)	118-121	Built-in effects 27
	122-125	Built-in effects 28
	126-129	Built-in effects 29
	130-133	Built-in effects 30
	134-137	Built-in effects 31
	138-141	Built-in effects 32
	142-145	Built-in effects 33
	146-149	Built-in effects 34
	150-153	Built-in effects 35
	154-157	Built-in effects 36
	158-161	Built-in effects 37
	162-165	Built-in effects 38
	166-169	Built-in effects 39
	170-173	Built-in effects 40
	174-177	Built-in effects 41
	178-181	Built-in effects 42
	182-185	Built-in effects 43
	186-189	Built-in effects 44
	190-193	Built-in effects 45
	194-197	Built-in effects 46
	198-201	Built-in effects 47
	202-205	Built-in effects 48
	206-209	Built-in effects 49
	210-213	Built-in effects 50
	214-217	Built-in effects 51
	218-221	Built-in effects 52
	222-225	Built-in effects 53
	226-229	Built-in effects 54
	230-233	Auto Mode (Run built in effects 1-54)
CH6 (Prior to CH5)	234-237	DMX Sound mode1
	238-241	DMX Sound mode2
	242-255	DMX Sound mode3
	0-9	No Function (CH5 valid )
	10-15	Segment 1 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	16-21	Segment 2 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	22-27	Segment 3 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	28-33	Segment 4 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	34-39	Segment 5 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	40-45	Segment 6 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	46-51	Segment 7 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	52-57	Segment 8 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	58-63	Segment 9 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)

	64-69	Segment 10 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	70-75	Segment 11 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	76-81	Segment 12 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	82-87	Segment 13 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	88-93	Segment 14 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	94-99	Segment 15 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
	100-105	Segment 16 LED light up, CH2, CH3, CH4 control color (CH7>100, the other LED segments are off)
CH6	106-111	Pattern Effect 1(CH2, CH3, CH4 Control pattern color)
	112-117	Pattern Effect 2(CH2, CH3, CH4 Control pattern color)
	118-123	Pattern Effect 3(CH2, CH3, CH4 Control pattern color)
	124-129	Pattern Effect 4(CH2, CH3, CH4 Control pattern color)
	130-135	Pattern Effect 5(CH2, CH3, CH4 Control pattern color)
	136-141	Pattern Effect 6(CH2, CH3, CH4 Control pattern color)
	142-147	Pattern Effect 7(CH2, CH3, CH4 Control pattern color)
	148-153	Pattern Effect 8(CH2, CH3, CH4 Control pattern color)
	154-159	Pattern Effect 9(CH2, CH3, CH4 Control pattern color)
	160-165	Pattern Effect 10(CH2, CH3, CH4 Control pattern color)
	166-171	Pattern Effect 11(CH2, CH3, CH4 Control pattern color)
	172-177	Pattern Effect 12(CH2, CH3, CH4 Control pattern color)
	178-183	Pattern Effect 13(CH2, CH3, CH4 Control pattern color)
	184-189	Pattern Effect 14(CH2, CH3, CH4 Control pattern color)
	190-195	Pattern Effect 15(CH2, CH3, CH4 Control pattern color)
	196-201	Pattern Effect 16(CH2, CH3, CH4 Control pattern color)
	202-207	Pattern Effect 17(CH2, CH3, CH4 Control pattern color)
	208-213	Pattern Effect 18(CH2, CH3, CH4 Control pattern color)
	214-219	Pattern Effect 19(CH2, CH3, CH4 Control pattern color)
	220-225	Pattern Effect 20(CH2, CH3, CH4 Control pattern color)
	226-231	Pattern Effect 21(CH2, CH3, CH4 Control pattern color)
	232-237	Pattern Effect 22(CH2, CH3, CH4 Control pattern color)
	238-243	Pattern Effect 23(CH2, CH3, CH4 Control pattern color)
	244-255	Pattern Effect 24(CH2, CH3, CH4 Control pattern color)
CH7	0-255	DMX Program Speed (Slow->fast)
	0-9	No function
	10-19	Static color 1 (10<=CH5 Value <=13)
	20-29	Static color 2 (10<=CH5 Value <=13)
	30-39	Static color 3 (10<=CH5 Value <=13)
	40-49	Static color 4 (10<=CH5 Value <=13)
	50-59	Static color 5 (10<=CH5 Value <=13)
	60-69	Static color 6 (10<=CH5 Value <=13)
	70-79	Static color 7 (10<=CH5 Value <=13)
	80-89	Static color 8 (10<=CH5 Value <=13)
	90-99	Static color 9 (10<=CH5 Value <=13)
	100-109	Static color 10 (10<=CH5 Value <=13)
	110-119	Static color 11 (10<=CH5 Value <=13)

CH7	120-129	Static color 12 (10<=CH5 Value <=13)
	130-139	Static color 13 (10<=CH5 Value <=13)
	140-149	Static color 14 (10<=CH5 Value <=13)
	150-159	Static color 15 (10<=CH5 Value <=13)
	160-169	Static color 16 (10<=CH5 Value <=13)
	170-179	Static color 17 (10<=CH5 Value <=13)
	180-189	Static color 18 (10<=CH5 Value <=13)
	190-199	Static color 19 (10<=CH5 Value <=13)
	200-209	Static color 20 (10<=CH5 Value <=13)
	210-219	Static color 21 (10<=CH5 Value <=13)
	220-229	Static color 22 (10<=CH5 Value <=13)
	230-239	Static color 23 (10<=CH5 Value <=13)
	240-249	Static color 24 (10<=CH5 Value <=13)
	250-255	Static color 25 (10<=CH5 Value <=13)
CH8	0-9	No Function
	10-255	Strobe (Strobe) Slow->Fast

#### DMX MODE4:24CH

CH1	0-255	Dimmer (Master dimmer)
CH2	0-255	ALL RED (0-100%)
CH3	0-255	ALL GREEN (0-100%)
CH4	0-255	ALL BLUE (0-100%)
CH5 (When CH6 value <10,This dmx channels is valid )	0-9	No Function (CH2-Ch4,CH9-CH24 Valid )
	10-13	Static color (CH7 )
	14-17	Built-in effects 1
	18-21	Built-in effects 2
	22-25	Built-in effects 3
	26-29	Built-in effects 4
	30-33	Built-in effects 5
	34-37	Built-in effects 6
	38-41	Built-in effects 7
	42-45	Built-in effects 8
	46-49	Built-in effects 9
	50-53	Built-in effects 10
	54-57	Built-in effects 11
	58-61	Built-in effects 12
	62-65	Built-in effects 13
	66-69	Built-in effects 14
	70-73	Built-in effects 15
	74-77	Built-in effects 16
	78-81	Built-in effects 17
	82-85	Built-in effects 18
	86-89	Built-in effects 19
	90-93	Built-in effects 20
	94-97	Built-in effects 21
	98-101	Built-in effects 22
	102-105	Built-in effects 23
	106-109	Built-in effects 24

CH5 (When CH6 value <10, this dmx channel is valid )	110-113	Built-in effects 25
	114-117	Built-in effects 26
	118-121	Built-in effects 27
	122-125	Built-in effects 28
	126-129	Built-in effects 29
	130-133	Built-in effects 30
	134-137	Built-in effects 31
	138-141	Built-in effects 32
	142-145	Built-in effects 33
	146-149	Built-in effects 34
	150-153	Built-in effects 35
	154-157	Built-in effects 36
	158-161	Built-in effects 37
	162-165	Built-in effects 38
	166-169	Built-in effects 39
	170-173	Built-in effects 40
	174-177	Built-in effects 41
	178-181	Built-in effects 42
	182-185	Built-in effects 43
	186-189	Built-in effects 44
	190-193	Built-in effects 45
	194-197	Built-in effects 46
	198-201	Built-in effects 47
	202-205	Built-in effects 48
	206-209	Built-in effects 49
	210-213	Built-in effects 50
	214-217	Built-in effects 51
	218-221	Built-in effects 52
	222-225	Built-in effects 53
	226-229	Built-in effects 54
	230-233	Auto Mode(Run built in effects 1-54)
	234-237	DMX Sound mode1
	238-241	DMX Sound mode2
	242-255	DMX Sound mode3
CH6 (Prior to CH5)	0-9	No Function(CH5 Valid)
	10-19	Pattern Effects 1 (CH2, CH3, CH4 Control pattern color)
	20-29	Pattern Effects 2 (CH2, CH3, CH4 Control pattern color)
	30-39	Pattern Effects 3 (CH2, CH3, CH4 Control pattern color)
	40-49	Pattern Effects 4 (CH2, CH3, CH4 Control pattern color)
	50-59	Pattern Effects 5 (CH2, CH3, CH4 Control pattern color)
	60-69	Pattern Effects 6 (CH2, CH3, CH4 Control pattern color)
	70-79	Pattern Effects 7 (CH2, CH3, CH4 Control pattern color)
	80-89	Pattern Effects 8 (CH2, CH3, CH4 Control pattern color)
	90-99	Pattern Effects 9 (CH2, CH3, CH4 Control pattern color)
	100-109	Pattern Effects 10 (CH2, CH3, CH4 Control pattern color)
	110-119	Pattern Effects 11 (CH2, CH3, CH4 Control pattern color)
	120-129	Pattern Effects 12 (CH2, CH3, CH4 Control pattern color)
	130-139	Pattern Effects 13 (CH2, CH3, CH4 Control pattern color)
	140-149	Pattern Effects 14 (CH2, CH3, CH4 Control pattern color)

CH6 (Prior to CH5)	150-159	Pattern Effects 15 (CH2, CH3, CH4 Control pattern color)
	160-169	Pattern Effects 16 (CH2, CH3, CH4 Control pattern color)
	170-179	Pattern Effects 17 (CH2, CH3, CH4 Control pattern color)
	180-189	Pattern Effects 18 (CH2, CH3, CH4 Control pattern color)
	190-199	Pattern Effects 19 (CH2, CH3, CH4 Control pattern color)
	200-209	Pattern Effects 20 (CH2, CH3, CH4 Control pattern color)
	210-219	Pattern Effects 21 (CH2, CH3, CH4 Control pattern color)
	220-229	Pattern Effects 22 (CH2, CH3, CH4 Control pattern color)
	230-239	Pattern Effects 23 (CH2, CH3, CH4 Control pattern color)
	240-255	Pattern Effects 24 (CH2, CH3, CH4 Control pattern color)
	154-159	Pattern Effects 9 (CH2, CH3, CH4 Control pattern color)
	160-165	Pattern Effects 10 (CH2, CH3, CH4 Control pattern color)
	166-171	Pattern Effects 11 (CH2, CH3, CH4 Control pattern color)
	172-177	Pattern Effects 12 (CH2, CH3, CH4 Control pattern color)
	178-183	Pattern Effects 13 (CH2, CH3, CH4 Control pattern color)
	184-189	Pattern Effects 14 (CH2, CH3, CH4 Control pattern color)
	190-195	Pattern Effects 15 (CH2, CH3, CH4 Control pattern color)
	196-201	Pattern Effects 16 (CH2, CH3, CH4 Control pattern color)
	202-207	Pattern Effects 17 (CH2, CH3, CH4 Control pattern color)
	208-213	Pattern Effects 18 (CH2, CH3, CH4 Control pattern color)
	214-219	Pattern Effects 19 (CH2, CH3, CH4 Control pattern color)
	220-225	Pattern Effects 20 (CH2, CH3, CH4 Control pattern color)
	226-231	Pattern Effects 21 (CH2, CH3, CH4 Control pattern color)
	232-237	Pattern Effects 22 (CH2, CH3, CH4 Control pattern color)
	238-243	Pattern Effects 23 (CH2, CH3, CH4 Control pattern color)
	244-255	Pattern Effects 24 (CH2, CH3, CH4 Control pattern color)
CH7	0-255	DMX Program Speed(Slow->fast)
	0-9	No function
	10-19	Static color 1 (10<=CH5 Value <=13)
	20-29	Static color 2 (10<=CH5 Value<=13)
	30-39	Static color 3 (10<=CH5 Value<=13)
	40-49	Static color 4 (10<=CH5 Value<=13)
	50-59	Static color 5 (10<=CH5 Value<=13)
	60-69	Static color 6 (10<=CH5 Value<=13)
	70-79	Static color 7 (10<=CH5 Value<=13)
	80-89	Static color 8 (10<=CH5 Value<=13)
	90-99	Static color 9 (10<=CH5 Value<=13)
	100-109	Static color 10 (10<=CH5 Value<=13)
	110-119	Static color 11 (10<=CH5 Value<=13)
	120-129	Static color 12 (10<=CH5 Value<=13)
	130-139	Static color 13 (10<=CH5 Value<=13)
	140-149	Static color 14 (10<=CH5 Value<=13)
	150-159	Static color 15 (10<=CH5 Value<=13)
	160-169	Static color 16 (10<=CH5 Value<=13)
	170-179	Static color 17 (10<=CH5 Value<=13)
	180-189	Static color 18 (10<=CH5 Value<=13)
	190-199	Static color 19 (10<=CH5 Value<=13)
	200-209	Static color 20 (10<=CH5 Value<=13)
	210-219	Static color 21 (10<=CH5 Value<=13)

	220-229	Static color 22 (10<=CH5 Value<=13)	
	230-239	Static color 23 (10<=CH5 Value<=13)	
	240-249	Static color 24 (10<=CH5 Value<=13)	
	250-255	Static color 25 (10<=CH5 Value<=13)	
CH8	0-9	No Function	
	10-255	Slow->Fast	Strobe (Strobe)
CH9	0-255	Segment 1 LED dimmer	
CH9	0-255	Segment 2 LED dimmer	
...	...	...	
CH23	0-255	Segment 15 LED dimmer	
CH24	0-255	Segment 16 LED dimmer	

#### DMX MODE5: 48CH

CH1	0-255	RED1 (0-100%)
CH2	0-255	GREEN1 (0-100%)
CH3	0-255	BLUE1 (0-100%)
CH4	0-255	RED2 (0-100%)
CH5	0-255	GREEN2 (0-100%)
CH6	0-255	BLUE2 (0-100%)
---	---	---
CH46	0-255	RED16 (0-100%)
CH47	0-255	GREEN16 (0-100%)
CH48	0-255	BLUE16 (0-100%)

#### DMX MODE6: 53CH

CH1	0-255	Dimmer(Master Dimmer )
CH2	0-255	RED1 (0-100%)
CH3	0-255	GREEN1 (0-100%)
CH4	0-255	BLUE1 (0-100%)
CH5	0-255	RED2 (0-100%)
CH6	0-255	GREEN2 (0-100%)
CH7	0-255	BLUE2 (0-100%)
...	...	...
CH47	0-255	RED16 (0-100%)
CH48	0-255	GREEN16 (0-100%)
CH49	0-255	BLUE16 (0-100%)
CH50 (when CH51 value <10, this DMX channel is valid)	0-9	No Function (CH2-Ch49 Valid)
	10-13	Static color(CH52 Choose)
	14-17	Built-in effects 1
	18-21	Built-in effects2
	22-25	Built-in effects 3
	26-29	Built-in effects 4
	30-33	Built-in effects 5
	34-37	Built-in effects 6
	38-41	Built-in effects 7
	42-45	Built-in effects 8
	46-49	Built-in effects 9

CH50 (when CH51 value <10, this DMX channel is valid)	50-53	Built-in effects 10
	54-57	Built-in effects 11
	58-61	Built-in effects 12
	62-65	Built-in effects 13
	66-69	Built-in effects 14
	70-73	Built-in effects 15
	74-77	Built-in effects 16
	78-81	Built-in effects 17
	82-85	Built-in effects 18
	86-89	Built-in effects 19
	90-93	Built-in effects 20
	94-97	Built-in effects 21
	98-101	Built-in effects 22
	102-105	Built-in effects 23
	106-109	Built-in effects 24
	110-113	Built-in effects 25
	114-117	Built-in effects 26
	118-121	Built-in effects 27
	122-125	Built-in effects 28
	126-129	Built-in effects 29
	130-133	Built-in effects 30
	134-137	Built-in effects 31
	138-141	Built-in effects 32
	142-145	Built-in effects 33
	146-149	Built-in effects 34
	150-153	Built-in effects 35
	154-157	Built-in effects 36
	158-161	Built-in effects 37
	162-165	Built-in effects 38
	166-169	Built-in effects 39
	170-173	Built-in effects 40
	174-177	Built-in effects 41
	178-181	Built-in effects 42
	182-185	Built-in effects 43
	186-189	Built-in effects 44
	190-193	Built-in effects 45
	194-197	Built-in effects 46
	198-201	Built-in effects 47
	202-205	Built-in effects 48
	206-209	Built-in effects 49
	210-213	Built-in effects 50
	214-217	Built-in effects 51
	218-221	Built-in effects 52
	222-225	Built-in effects 53
	226-229	Built-in effects 54
	230-233	Auto Mode(Run Built-in effects 1-54)
	234-237	DMX Sound mode1
	238-241	DMX Sound mode2
	242-255	DMX Sound mode3

	0-9	No Function (CH50 Valid)
	10-19	Pattern effects 1 (CH2, CH3, CH4 Control pattern color)
	20-29	Pattern effects 2 (CH2, CH3, CH4 Control pattern color)
	30-39	Pattern effects 3 (CH2, CH3, CH4 Control pattern color)
	40-49	Pattern effects 4 (CH2, CH3, CH4 Control pattern color)
	50-59	Pattern effects 5 (CH2, CH3, CH4 Control pattern color)
CH51 (Prior to CH50)	60-69	Pattern effects 6 (CH2, CH3, CH4 Control pattern color)
	70-79	Pattern effects 7 (CH2, CH3, CH4 Control pattern color)
	80-89	Pattern effects 8 (CH2, CH3, CH4 Control pattern color)
	90-99	Pattern effects 9 (CH2, CH3, CH4 Control pattern color)
	100-109	Pattern effects 10 (CH2, CH3, CH4 Control pattern color)
	110-119	Pattern effects 11 (CH2, CH3, CH4 Control pattern color)
	120-129	Pattern effects 12 (CH2, CH3, CH4 Control pattern color)
CH51 (Prior to CH50)	130-139	Pattern effects 13 (CH2, CH3, CH4 Control pattern color)
	140-149	Pattern effects 14 (CH2, CH3, CH4 Control pattern color)
	150-159	Pattern effects 15 (CH2, CH3, CH4 Control pattern color)
	160-169	Pattern effects 16 (CH2, CH3, CH4 Control pattern color)
	170-179	Pattern effects 17 (CH2, CH3, CH4 Control pattern color)
	180-189	Pattern effects 18 (CH2, CH3, CH4 Control pattern color)
	190-199	Pattern effects 19 (CH2, CH3, CH4 Control pattern color)
	200-209	Pattern effects 20 (CH2, CH3, CH4 Control pattern color)
	210-219	Pattern effects 21 (CH2, CH3, CH4 Control pattern color)
	220-229	Pattern effects 22 (CH2, CH3, CH4 Control pattern color)
	230-239	Pattern effects 23 (CH2, CH3, CH4 Control pattern color)
	240-255	Pattern effects 24 (CH2, CH3, CH4 Control pattern color)
	0-255	DMX Program Speed (Slow->fast)
	0-9	No Function
CH52	10-19	Static color 1 (10<=CH50 Value<=13)
	20-29	Static color 2 (10<=CH50 Value<=13)
	30-39	Static color 3 (10<=CH50 Value<=13)
	40-49	Static color 4 (10<=CH50 Value<=13)
	50-59	Static color 5 (10<=CH50 Value<=13)
	60-69	Static color 6 (10<=CH50 Value<=13)
	70-79	Static color 7 (10<=CH50 Value<=13)
	80-89	Static color 8 (10<=CH50 Value<=13)
	90-99	Static color 9 (10<=CH50 Value<=13)
	100-109	Static color 10 (10<=CH50 Value<=13)
	110-119	Static color 11 (10<=CH50 Value<=13)
	120-129	Static color 12 (10<=CH50 Value<=13)
	130-139	Static color 13 (10<=CH50 Value<=13)
	140-149	Static color 14 (10<=CH50 Value<=13)
	150-159	Static color 15 (10<=CH50 Value<=13)
	160-169	Static color 16 (10<=CH50 Value<=13)
	170-179	Static color 17 (10<=CH50 Value<=13)
	180-189	Static color 18 (10<=CH50 Value<=13)
	190-199	Static color 19 (10<=CH50 Value<=13)
	200-209	Static color 20 (10<=CH50 Value<=13)
	210-219	Static color 21 (10<=CH50 Value<=13)
	220-229	Static color 22 (10<=CH50 Value<=13)
	230-239	Static color 23 (10<=CH50 Value<=13)
	240-249	Static color 24 (10<=CH50 Value<=13)
	250-255	Static color 25 (10<=CH50 Value <=13)
CH53	0-9	No Function
	10-255	Slow->Fast
		Strobe (Strobe)